
Chapter 7

Troubleshooting

General

This chapter provides information for diagnosing and correcting machine malfunctions.

NOTE

The controller displays error codes in the event of a malfunction. *Always* check the display for any messages before proceeding. *Always* check the formula to make sure the sequence is correct. Also check for incorrect user programmable set-up or set parameters which may be causing an error.

NOTE

If there is a main power failure the memory will hold the selected program for about 8-10 minutes. The machine will not restart automatically when power is restored.

NOTE

Always check AC voltage across phases, never to ground!

NOTE

Some error messages may not be displayed, depending on machine options.

Always start troubleshooting by making a thorough visual inspection of the equipment. Check the controller display for messages. Check circuit breakers, electrical connections, and switches for evidence of overheating and damage. Check all plumbing and pneumatic connections for leakage or damage.

Engineering drawings (pneumatic, electrical, etc., as required) are supplied with the machine and located in the back pocket of this manual for future reference. Refer to these drawings for specific machine information which is essential to the troubleshooting process.

Table 7-2 lists the various controller error messages, possible causes, and suggested remedies. The following Troubleshooting Table has information for diagnosing and correcting machine malfunctions that may not display an error message.

Maintenance prompts and other text prompts can be programmed. If a message is displayed that is not listed in Table 7-2 check to see if the message is a preventive maintenance prompt. The preventive maintenance prompt will be displayed, along with the message "Call Maintenance" at the programmed interval. Do not confuse a preventive maintenance prompt with an actual fault/error condition.

Machine Trouble Shooting Table

Table 7–1 Washer Trouble Shooting Table

No.	Symptom	Operator Action	Maintenance Action
Washer Does Not Start or Machine Operation Problem			
1.	Machine will not start.	a. Check display panel for power applied (display LEDs ON). b. Press the YES/START key on the formula controller. c. Check the Emergency Stop switch. d. Check the main circuit breaker to the machine. e. Check incoming air supply (if equipped) for 90 to 100 PSI (6 to 7 bar).	a. Check that shell door limit switches are operational. b. Check for variable speed drive fault. c. Check electrical power source.
2.	Formula will not run, incompatible step.	Programming error. Controller will display the step and the line number containing the instructions that are not compatible (example: fill and drain). Programmer must insert a step ending instruction between the incompatible steps.	
3.	Machine does not operate at process speed.	Call Maintenance.	a. Check motor and belts. b. Check the drive inverter for fault or error condition. Fault or error condition will be displayed on the inverter. c. Check dwell setting. The dwell setting time, is the time programmed between wash forward and wash reverse. This time can be set between 4–999 seconds.
4.	Machine shuts off or does not extract.	Check for excessively unbalanced load. Call Maintenance	a. Check for actuated or defective, vibration or unbalance switch. b. Check to see if the shell door, or the sample door interlock limit switches are dropping out (possibly due to machine vibration). c. Check that drain valve is fully open during extraction. d. Check for low air pressure, FVS machines only. The main air pressure switch may open if air pressure is low. e. For Floataire® machines, check if the machine’s shell and the unbalance switch and it’s window is centered prior to extract.

Table 7–1 Washer Trouble Shooting Table (continued)

No.	Symptom	Operator Action	Maintenance Action
Washer Does Not Start or Machine Operation Problem (continued)			
5.	Machine fails to restart after extraction.	<ul style="list-style-type: none"> a. Check display panel for power applied. b. Press the START key on the formula controller. c. Check the main circuit breaker to the machine. d. Check the main disconnect switch. e. Check incoming air supply, if equipped, for 90–100 psi (6–7 bar). f. Check door interlock. g. Check that shell door limit switch is tripped. 	
6.	Variable Speed Drive (inverter) does not operate (faulted), or experiences fault during washer operation.	<p>Check display on controller. If an inverter fault is displayed, “Variable Speed Drive Is Faulted” a level seven password has to be entered in the controller before the fault is reset. (refer to variable speed manual).</p> <p>Check if machine is loaded beyond maximum capacity.</p> <p>Call Maintenance.</p>	<ul style="list-style-type: none"> a. Enter a level 7 password to clear/reset the inverter fault. NOTE: Some inverter faults can not be reset. In this case, call the Washex Service Department. a. Check that the drain valve is fully open during extraction. b. Check if the cylinder bearings are overheated. c. Check electrical phases for low voltage. d. Check motor for grounded or loose connection. e. Check if cylinder bearings are overheated.
Water Related Problem			
1.	Water level is too high.	<ul style="list-style-type: none"> a. Check formula. 	<ul style="list-style-type: none"> a. Check air trap canister and tubing for leaks. Check all connections. b. Check water inlet valves for leakage. c. Calibrate water system. Refer to page 6–26. d. Check level deadband. Refer to page 6–28. e. Check for loose electrical connection.

Table 7–1 Washer Trouble Shooting Table (continued)

No.	Symptom	Operator Action	Maintenance Action
Water Related Problem (continued)			
2.	Water does not enter machine.	Make sure that the manual shut off valve is open.	f. Check for blocked air trap canister or tubing. g. Make sure water inlet valve is functioning properly. h. Check electrical connections. i. Check for power at solenoid valve.
3.	Water or supplies enter machine without water programmed.	Call Maintenance.	Check that inlet valve is fully closed and operates properly.
4.	Water continues to drain after the drain is shut off.	Call Maintenance.	a. Check drain valve gasket. b. Check electrical connections. c. Check for debris in drain valve.
5.	Water will not heat.	Call Maintenance.	a. Check steam valve, if equipped. b. Check for faulty temperature probe or wiring. c. Check for appropriate steam pressure.
6.	Water inlet valves not shutting off.	Call Maintenance.	a. Check for blocked air trap canister or tubing. b. Make sure water inlet valve is functioning properly. c. Check electrical connections. d. Check for power at solenoid valve. e. Make sure water inlet valve is not stuck open.
Draining Problem			
1.	Machine does not drain.	Call Maintenance	a. Check drain valve and solenoid for proper operation. b. Check drain output. c. Check DRAIN LEDs for indication. If ON, check for loose wire.
Loading/Unloading Shell Door Problem			
1.	Shell door leaks.	Call Maintenance.	a. Check condition of door gasket. b. Check tension between gasket and frame.
2.	Shell door glass leaks.	Call Maintenance.	a. Check torque of frame bolts. b. Replace glass seal.

Table 7–1 Washer Trouble Shooting Table (continued)

No.	Symptom	Operator Action	Maintenance Action
Loading/Unloading Shell Door Problem (continued)			
3.	Door does not open or close.	a. Check if there is water in machine. b. Check internal washer temperature, door will not open until temperature drops below 135° F or 57°C.	a. Make sure that a water level does not exist inside the machine. Door will not open if water level is above 3 inches. b. Check door open switch. c. Check if door interlock pin is retracted. d. Check for proper air pressure (FVS machines only). e. Check door interlock and solenoid wiring. f. Check water level system and calibration. Refer to page 6–26.
Drive Belt Related Problem			
1.	Drive belts squeal.	Call Maintenance.	a. Check tension of belts. b. Check that belts are dry and clean. c. Check sheave groove for wear.
Excessive Washer Vibration			
1.	Machine or frame vibrates excessively.	Check load distribution.	a. Check that machine is level in all directions and properly grouted. b. Tighten anchor bolts. Refer to page 4–4 for bolt torque values. c. Check shimming of frame base. d. If applicable, check Floataire® system, and proper height and centering of shell (FVS machines only).
Chemical / Supply Problem			
1.	Chemicals or supplies enter washer without being programmed.	Call Maintenance.	Check that inlet valve is fully closed and operates properly.
2.	Chemical pumps 1–8 (optional) do not operate.	Call Maintenance.	a. Check Machine Setups in Appendix 2C, and the chemical section in Chapter 5 (Start–Up). b. Make sure the chemical system is installed correctly. Refer to the chemical supply section, page 4–8, in the Installation Chapter. c. The chemical instruction will be ignored until the calibration has been performed. Make sure the chemicals have been calibrated. Refer to page 5–39.

Table 7-1 Washer Trouble Shooting Table (continued)

No.	Symptom	Operator Action	Maintenance Action
Chemical / Supply Problem (continued)			
3.	Manual flush 6-7 (optional) instructions do not appear as an instruction choice.	Call Maintenance	Check the Machine Setups in Appendix 2C.
4.	Incorrect amount of automatic chemical injected.	Call Maintenance	a. Calibrate chemical pumps, page 5-39. b. Make sure the appropriate units are assigned. Refer to page 5-36 in the Start-Up Chapter.
5.	Manual chemicals not totaled.	Call Maintenance	Insert a chemical instruction prior to the flush instruction. A chemical instruction must be programmed before the flush instruction. The chemical instruction reports the amount of chemical so this can be added to the totals.

Controller Error Codes

NOTE

The controller will display error codes in the event of a malfunction. Refer to the following table for the display message, possible cause, and action to take if a machine malfunction.

Use the status keys (1-9) while a formula is running to obtain more information.

Some error messages might not be displayed, depending on machine options.

1. Error Messages

Maintenance prompts can be programmed by the customer. If a message is displayed that is not listed in Table 7-2, then check to see if the message is a preventive maintenance prompt. The preventive maintenance prompt will be displayed, along with the message “Call Maintenance” at the programmed interval. Text prompt can also be programmed. This will be displayed along with a signal. *Do not* confuse a preventive maintenance prompt or other text prompt with an actual trouble.

Table 7-2 Error Messages

Message	Possible Cause	Action
Checksum ¹	Error on I ² C bus.	Check EEPROM, I/O racks 1–8, ribbon cable, processor card, and motherboard.
Start Error	Memory invalid or program corrupted, missing end of formula marker.	Clear all programs, operations, and vocabs (formula may have been programmed prior to initializing memory by clearing all programs, operations and vocabs).
Memory Card Might be Corrupted	User setup corrupted.	Perform user setup, clear all programs, operations, and vocabs. Refer to Clearing Memory Corrupt procedure in Appendix 2C, page 2C-32 .
Incompatible Steps Error	Group 1 and 2 instructions programmed on the same step.	Change program.
I/O Rack No. 1–8 Fault ²	I/O card bad.	Clear watchdog and check I/O card.
Check Power Circuit	Wiring short, blown 24 VAC control fuse.	Repair wiring short and replace fuse.
P.B. (Pushbutton) Chip No.1–4 Fault ²	Chip not responding.	Check ribbon cable and P.B. chip in display enclosure.
Access Denied	Password does not have access to selected function.	Enter correct level password.
RPM too Low ²	RPM sensor check prior to extract failed. Drive slipping or sensor bad.	Check belt tension, check rpm sensor.

Table 7–2 Error Messages (continued)

Message	Possible Cause	Action
Invalid Memory Copy		
Sample Door Open		Close sample door.
Chemical Watchdog (Chemical 1–16) ²	Automatic chemical pump on too long.	Check supply inlets and pumps.
Extract Retry	Unbalanced load.	Machine will retry 3 times, if programmed.
Extract Unbalance	Unbalanced load.	Extract retry failed or no retry selected. Check loading, raise extract retry level (if programmed), raise water level, check mounting bolts, check unbalance switch adjustment.
Low Air Pressure ²	Pressure below 70 psi.	Check compressed air supply.
Variable Speed Drive Fault ²	Variable speed drive error.	Check display on drive controller for messages. Check error history in drive controller. Refer to variable speed drive manual.
Water Fill Watchdog ²	Machine did not fill to programmed level.	Check manual shut-off, water, drain valves, and water pressure.
Steam Injection Watchdog ²	Machine did not heat to programmed level.	Check steam manual shut-off and steam valves.
Steam Gradient Watchdog ²	Machine unable to reach the desired programmed gradient.	Check: steam pressure, manual shut-off and steam valve.
Cooldown Watchdog ²	Polyrinse not operating.	Check valve.
Level Halt High ²	Level too high.	Check water valve, sensor, and drain.
Temp. Halt Low ²	Temperature too low.	Check steam valve, sensor, and temperature probe.
Temp. Halt High ²	Temperature too high.	Check steam valve and temperature probe.
Reset 15A Circuit Breaker	15 amp breaker tripped.	Reset breaker.
Reset Overloads	Motor overload tripped.	Wait 5 minutes then reset overload. If overload trips again, check: drain is open during extract, voltage level, clutch released.
Clutch Speed Too Low ² (if equipped)	Clutch (if installed) sensor check prior to extract failed. Belts loose, sensor bad.	Check clutch operation and clutch sensor.
Clutch Overspeed ¹ (if equipped)	Clutch not releasing properly.	Call Washex. Check clutch quick exhaust valve, and clutch sensor adjustment.
Door Not Closed	Door closed switch open.	Close door. Check door interlock proximity switch.
Sensor 1–3 Leak		Check automatic chemical flow sensor system for leaks.


¹ Contact Washex service department to clear error.
² Requires maintenance password to clear error.

2. Clearing Watchdog Errors

A fault watchdog (error message) will be displayed any time the controller detects an error condition. The error message will indicate the type of fault. Machine operation will be halted until a level five password or above is entered.

Many watchdog functions are programmable. If excessive errors are encountered, the watchdog setting may be incorrect. Also refer to the Maintenance Chapter, page 6-2, for information on preventive maintenance watchdogs.


Refer to Table 7-2 for a list of error messages and possible corrective actions.



Call Maintenance!!
Water Fill Watchdog!
Fill Hot

- a. Check the machine to try to determine why the fault occurred. Try to note as much information about the condition of the machine as possible. This information will help the maintenance technician determine the cause of the fault, if necessary.
- b. If the machine is equipped with variable speed drive and a drive fault message is displayed, check the variable speed drive controller display for additional messages. The technician may also check the error history in the drive controller.

- c. Press the “Clear”  key then enter a valid password, level five (default = 555555) through level seven (default = 777777). The following display will appear.



Formula # 1
Step # 1 Line # 2
PAUSED! [YES] Starts
T = 0:57 S = 1:00



NOTE

The machine is programmed with default passwords at the factory, but they can be reprogrammed after the machine is entered into service.

- d. The watchdog message disappears. Press the “Yes”  key to restart the formula. The display will show current formula, step, and line number.
- e. If the error is still present, press the “Enter”  and “No”  keys to cancel the formula.
- f. If the error persists, the watchdog message will be displayed again. The error must be corrected before the machine can be operated.

Diagnostics

Use this procedure to manually test the operator console and inputs to the controller. This procedure is also used to display the number of times each I/O rack board failed to respond to a request from the controller.

Waiting for Washer
to Receive Load!!
Depress [YES] Key to
Select Formula

1. Enter a valid password (level 3, default = 333333, through level 7, default = 777777) from the Waiting to Load menu. If the Waiting to Unload message is displayed, press the “No”  and “Enter”  keys simultaneously.

The main password protected menu is displayed.

1 = Setup 2 = Program
3 = Maint. 4 = Calib.
5 = Totals 6 = Clock
Selection? 0=exit

2. Select item 3, Maintenance.

1 = Manual Outputs
2 = Diagnostics
3 = Maintenance
Selection? 0=exit

3. Select item 2, Diagnostics.

1 = Test Front Panel
2 = Display Inputs
3 = Board Responses
Selection? 0=exit

1. Test Front Panel

- a. Select item 1, Test Front Panel.

Press Any Key Or
Pushbutton To Test.

YES+NO = Exit

- b. The time display will show a number corresponding to the location of the active switch. If no number is displayed, either the switch is faulty or the corresponding electrical circuit has a bad component.

Refer to Figure 7-8 for the correct numbering sequence for the front panel test.

This test is also useful for isolating burned out bulbs in the manual switches. If the switch number is displayed (controller receiving signal) but the light is not illuminated, either the bulb is burned out, or the corresponding electrical circuit is faulty.

- c. Press the “Yes”  and “No”  keys to terminate the front panel test.






Figure 7-8 Correct Display for Front Panel Test

2. Display Inputs and Outputs

- a. Select item 2, Display Inputs. Refer to the control circuit diagram for the description of each input and output.



- b. Use the “Up”  and “Down”  arrow keys to scroll to the desired input. The corresponding LED, on the input module should be on if the status indicator shows the input is on.
- c. To view the status of the outputs, press the “Up”  and “Down”  arrow keys at the same time. If required, use the arrow keys to scroll to see the remainder of the inputs. The outputs can be viewed at any time. Press the “Enter”  key to return to the Input display.



-
- d. Press 0 to terminate the test.

3. Board Responses

Due to the nature of the electronic timing signals, the I/O racks and boards will fail to respond to the controller a small percentage of the time.

The controller will repeat the request until the board responds. If the controller receives four sequential no-responses, an error message is displayed. An excessive number of repeat requests may indicate a failing auxiliary I/O rack or a bad connection.

- a. Select item 3, Board Responses. “No responses = 0” means the board is working perfectly.

```
I/O Rack #1
No Responses = 0
Use arrows to scroll
0 = exit
```

- b. Use the “Up”  and “Down”  arrows to scroll through the boards. Auxiliary I/O racks, analog boards, and push button boards are shown.

- c. Press 0 to exit the board response test.

```
1 = Test Front Panel
2 = Display Inputs
3 = Board Responses
Selection?           0=exit
```

4. Serial Communication Board for Variable Speed Drive Inverter (if equipped)

NOTE

This section is for machines equipped with a variable speed drive inverter.

CAUTION

Disconnect the main power from the machine before removing the variable speed drive (inverter) cover.

The controller communicates to the variable speed drive inverter using a serial signal. This signal tells the inverter how fast or slow the drive motor is supposed to turn. Due to this means of communication, there is not a variable voltage - drive RPM reference like in an analog signal. To locate the communication card, disconnect the electrical power from the washer and remove the front cover from the inverter. Refer to the illustration below for more information.

Variable Speed Drive Inverter,
with Cover Removed



There are four communication LEDs located on the serial communication card. Under normal machine operations, the outside LEDs will be blinking. This is a visual indication that the controller is transmitting signals to the inverter, and that the inverter is responding to the signals. Only during a fault or error condition will one or both of the inner LEDs be illuminated. If an error or fault condition is discovered, call the Washex Service Department at 1-940-855-3990.

Outer LEDs Blinking = Normal Operations
Inner LED(s) Illuminated = Fault or Error Condition

Communication LEDs

Serial Communication Cable
and Plug, from Controller




Figure 7-9 Serial Communication Board

5. Preventive Maintenance

Refer to the Maintenance Chapter for information concerning the preventive maintenance watchdog system capabilities.