

(Recommended wax cloth & chest cleaner instruction based on a 40-hour work week)

## **FH Bonn**

### **Chest Cleaner Instructions**

1. Make sure you put aprons and folder on by-pass when running chest cleaner through ironer and make sure ironer is hot.
2. Run chest cleaner through ironer before waxing and before ironing linens each day.
3. Run chest cleaner through ironer repeatedly until chests are clean, and be sure chest cleaner is fed to extreme ends of chests.
4. Run 3 to 4 soiled linens after using chest cleaner to remove any excess dirt left behind by chest cleaner. **DO NOT USE WAX CLOTH** for this purpose it will just get dirty.
5. Now ironer should be ready for waxing.

### **Wax cloth instructions**

1. Make sure vacuum is OFF when waxing.
2. Feed leading edge of wax cloth into first chest of hot ironer. Leave flap outside of finger roll. Stop ironer.
3. Evenly spread approximately ½ cup or one handful of wax per roll under flap. Fold flap back over waxed area and run wax cloth through ironer.
4. Follow-morning waxing with 3 or 4 soiled linens to remove any excessive wax. Run wax cloth empty at noon.
5. Run wax cloth through ironer before feeding linens each day, only applying wax preferably Monday morning & Wednesday morning, Also run wax cloth through ironer each day at noon without any wax under flap.